



Turn Around Times

Aadva Zr Coping	Single unit	3 business days
	Custom Design (double scan, CAD designing)	4 business days
	Coping Bridge 2-4 units	4 business days
Aadva Zr Abutment	Wax up provided	3 business days
	GCAT Design 1-5 units	4 business days
	GCAT Design 6 units or more	5 business days
	With Zr coping	Add 2 business days
Aadva Ti Abutment	Wax up provided	2 business days
	GCAT Design 1-5 units	3 business days
	GCAT Design 6 units or more	4 business days
	With Zr coping	Add 2 business days

GC Advanced Technologies listed turn around times begin on the first business day after receipt of all case information